HOW TO USE THIS MANUAL

GENERAL INFORMATION

1. GENERAL DESCRIPTION

- (a) This manual is made in accordance with SAE J2008.
- (b) Generally, repair operations can be separated in the following 3 main processes:
 - 1. Diagnosis
 - 2. Removing and Installing, Replacing, Disassembling, Installing and Checking, Adjusting
 - 3. Final Inspection
- (c) This manual explains the 1st process of "Diagnosis" (placed in the "Diagnostics" section), the 2nd process of "Removing and Installing, Replacing, Disassembling, Installing and Checking, Adjusting", but the 3rd process of "Final Inspection" is omitted.
- (d) The following essential operations are not written in this manual. However, these operations must be done in the practical situation.
 - (1) Operation with a jack or lift
 - (2) Cleaning of a removed part when necessary
 - (3) Visual check

2. INDEX

(a) An alphabetical INDEX is provided as a section on the end of the book to guide you to the item to be repaired.

3. PREPARATION

(a) Use of special service tools (SST) and special service materials (SSM) may be required, depending on the repairing condition. Be sure to use SST and SSM when they are required and follow the working procedure properly. A list of SST and SSM is in the Preparation section of this manual.

4. **REPAIR PROCEDURES**

- (a) Component drawing is placed under the title when necessary.
- (b) Illustrations are placed as "disassembled parts drawing" so that it enables you to understand the fitting condition of the components.
- (c) Non-reusable parts, grease applied parts, precoated parts and tightening torque are specified in the components drawing.

Example:



01-1

INTRODUCTION - HOW TO USE THIS MANUAL

(d) Tightening torque, oil applying position, and non-reusable parts are described as important points in the procedure.

NOTICE:

There are cases where such information can only be indicated by an illustration. In that case, all the information such as torque, oil, etc. are described in the illustration.

- (e) Installing procedure of operation items is performed in the reverse order of the removal, and only the important points are described.
- (f) Only items with points are described in the procedure, and the operational portion and content are placed using an illustration. In the explanations, details of the operational method, standard value and notice are placed.
- (g) There may be a case where the illustrations of the similar models are used. In that case the details may be different from the actual vehicle.
- (h) The procedures are presented in a step-by-step format:
 - (1) The illustration shows what to do and where to do it.
 - (2) The task heading tells what to do.
 - (3) The detailed text tells how to perform the task and gives other information such as specifications and warnings.

Example:

Illustration:

what to do and where



	Task heading: what to do
4.	INSTALL FRONT AXLE HUB LH BEARING
a)	Using SST and a press, install a new bearing to the steer- ing knuckle. Detailed test: how to perform task SST 09950-60020 (09951-00720), 09950-70010 (09951-07100) Set part No. Component part No.

D26745

HINT:

This format provides an experienced technician with a FAST TRACK to the necessary information. The task heading can be read at a glance when necessary, and the text below provides detailed information. Important specifications and warnings always stand out in bold type.

5. SERVICE SPECIFICATIONS

(a) Specifications are presented in bold type throughout the manual. You never have to leave the procedure to look up your specifications. The specifications are also found in the Service Specifications section for a quick reference.

6. TERMS DEFINITION

CAUTION	Indicate the possibility of injury to you or other people.
NOTICE	Indicate the possibility of damage to the components being repaired.
HINT	Provide additional information to help you to perform the repair efficiently.

7. SI UNIT

(a) The UNITS given in this manual are primarily expressed according to the SI UNIT (International System of Unit), and alternately expressed in the metric system and in the English System. Example:

Torque: 30 N·m (310 kgf·cm, 22 ft·lbf)

IDENTIFICATION INFORMATION VEHICLE IDENTIFICATION AND SERIAL NUMBERS



VEHICLE IDENTIFICATION NUMBER

The vehicle identification number is stamped on the vehicle identification number plate and the certification label, as shown in the illustration.

01041-02

A: Vehicle Identification Number Plate B: Certification Label

2. FACTORY OF PRODUCTION

(a) World manufacture identifier is used to distinguish between TMC and TMMK made vehicles. The first 3 digits and letters of the vehicle identification number shows the world manufacturer identifier.

	WMI *
TMC made	JTD
TMMK made	4T1

*: World Manufacturer Identifier

- 3. ENGINE SERIAL NUMBER AND TRANSAXLE SERIAL NUMBER
- (a) The engine serial number is stamped on the cylinder block of the engine, and the transaxle serial number is stamped on the housing, as shown in the illustration.
 - A: Engine Serial Number
 - **B: Transaxle Serial Number**





REPAIR INSTRUCTION

PRECAUTION

- 1. BASIC REPAIR HINT
- (a) HINTS ON OPERATIONS



-				
1	Looks	Always wear a clean uniform.Hat and safety shoes must be worn.		
2	Vehicle protection	Set a grill cover, fender cover, seat cover and floor mat before starting the operation.		
3	Safe operation	 In case of working with 2 or more persons, be sure to check safety of one another. When working with the engine running, pay attention to the ventilation of the workshop. In case of operating on a high-temperature parts, rotating, moving and vibrating parts, pay attention to not burn or injure yourself. When jacking up the vehicle, be sure to support the specified location with a safety stand. When lifting up the vehicle, apply a safety equipment. 		
4	Preparation of tools and measuring gauge	• Before starting operation, prepare a tool stand, SST, gauge, oil, shop rag and parts for replacement.		
5	Removal and installation, disassembly and assem- bly operations	 Diagnose with a thorough understanding of the trouble phenomenon and perform effective operations. Before removing the parts, check the assembly for general condition, deformation and damage. When the structure is complicated, take a note or put matchmarks so as not to make mistakes that affect the function of the parts. Clean and wash the removed parts if necessary, and assemble them after a thorough check. 		
6	Removed parts	 Place the removed parts in the correct order to avoid mixing up or making them dirty. As for non-reusable parts such as gasket, O-ring, and self lock nut, change them to new ones following the instruction of this manual. Sort out the parts for replacement in a box and show them to the customer. 		
<i>/</i> 1 \				

(b) JACKING UP AND SUPPORTING VEHICLE

Care must be taken when jacking up and supporting the vehicle. Be sure to lift and support the vehicle at the proper locations (See page 01–18).

2002 CAMRY REPAIR MANUAL (RM881U)

01042-02

01–5



(c) PRECOATED PARTS

- (1) Precoated parts are bolts, nuts, etc. that are coated with a seal lock adhesive at the factory.
- (2) If a precoated part is retightened, loosened or caused to move in any way, it must be recoated with the specified adhesive.
- (3) When reusing precoated parts, clean off the old adhesive and dry the part with compressed air. Then apply the specified seal lock adhesive to the bolt, nut or threads.

NOTICE:

Perform the torque checking with the lower limit value of the torque tolerance.

(4) Depending on the seal lock agent to apply, there may be a case where it is necessary to leave it for a specified time until it hardens.

- (d) GASKETS
 - (1) When necessary, use a sealer on gaskets to prevent leaks.

BE1367

- (e) BOLTS, NUTS AND SCREWS
 - (1) Carefully observe all the specifications for tightening torques. Always use a torque wrench.
 - Medium Current Fuse and High Current (f) Fuse Equal Amperage Rating

FUSES

 When replacing fuses, be sure that a new fuse has the correct amperage rating. DO NOT exceed the rating, or use one with a lower rating.

Illustration	Symbol	Part Name	Abbreviation
6300 BE5594		FUSE	FUSE
BE5595		MEDIUM CURRENT FUSE	M-FUSE
D27353		HIGH CURRENT FUSE	H-FUSE

(g) CLIPS

(1) The removal and installation methods of typical clips used in body parts are shown in the table below.

HINT:

If the clip is damaged during the operation, always replace it with a new clip.



D25786

01–7



2002 CAMRY REPAIR MANUAL (RM881U)





- TORQUE WHEN USING TORQUE WRENCH WITH EX-TENSION TOOL
 - (1) When a SST or extension tool is combined with the torque wrench to extend its entire length, if you tighten until the reading of the torque wrench reaches the specified torque value, the actual torque becomes excessive.
 - (2) In this manual, only the specified torque is described. In case of using SST or extension tool, calculate the reading of the torque wrench by the following formula.
 - (3) Formula T'=T x L2/(L1 + L2)

T'	Reading of torque wrench {N·m (kgf·cm, ft·lbf)}
Т	Torque {N·m (kgf·cm, ft·lbf)}
L1	Length of SST or extension tool (cm)
L2	Length of torque wrench (cm)

2. FOR VEHICLES EQUIPPED WITH SRS AIRBAG AND SEAT BELT PRETENSIONER HINT:

CAMRY is equipped with an SRS (Supplemental Restraint System), such as the driver airbag, front passenger airbag, side airbag, curtain shield airbag and seat belt pretensioner.

Failure to carry out the service operations in the correct sequence could cause the supplemental restraint system to unexpectedly deploy during servicing. It may lead to a serious accident.

Furthermore, if a mistake is made in servicing the supplemental restraint system, it is possible that the SRS will fail to operate when required. Before servicing (including removal or installation of parts, inspection or replacement), be sure to read the following items carefully. Then follow the correct procedure described in this manual.

- (a) GENERAL NOTICE
 - (1) Malfunction symptoms of the supplemental restraint system are difficult to confirm, so the diagnostic trouble codes become the most important source of information when troubleshooting. When troubleshooting the supplemental restraint system, always check the diagnostic trouble codes before disconnecting the battery (See page 05–690).
 - (2) Work must be started after 90 seconds from the time the ignition switch is turned to the "LOCK" position and the negative (–) terminal cable is disconnected from the battery.

(The supplemental restraint system is equipped with a back-up power source, so, if work is started within 90 seconds after disconnecting the negative (-) terminal cable from the battery, the SRS may deploy.)

When the negative (–) terminal cable is disconnected from the battery, memory of the clock and audio systems will be cancelled. So, before starting work, make a record of the memorized contents in each memory system. Then, when work is finished, reset the clock and audio systems as before. To avoid erasing the memory in each memory system, never use a back–up power supply from another battery.

(3) Even in case of a minor collision where the SRS does not deploy, the horn button assembly, instrument panel passenger airbag assembly, front seat airbag assembly, curtain shield airbag assembly and seat belt pretensioner should be inspected (See pages 60–17, 60–34, 60–44, 60–50 and 61–9).

2002 CAMRY REPAIR MANUAL (RM881U)

(4)	Never use SRS related parts from another vehicle. When replacing parts, replace them with new parts.
(5)	Before repairs, remove the airbag sensor if shocks are likely to be applied to the sensor during repairs.
(6)	Never disassemble and repair the airbag sensor assembly, horn button assembly, instrument panel passenger airbag assembly, front seat airbag assembly and the curtain shield airbag assembly or seat belt pretensioner.
(7)	If the airbag sensor assembly, the side airbag sensor assembly, the horn button assembly, the instrument panel passenger airbag assembly, the front seat airbag assembly or the curtain shield airbag assembly have been dropped, or if there are cracks, dents or other defects in the case, bracket or connector, replace them with new ones.
(8)	Do not directly expose the airbag sensor assembly, the horn button assembly, the instrument panel passenger airbag assembly, the front seat airbag assembly, the curtain shield airbag assembly or the seat belt pretensioner to hot air or flames.

- (9) Use a volt/ohmmeter with high impedance (10 k Ω /V minimum) for troubleshooting of an electrical circuit.
- (10) Information labels are attached to the SRS components. Follow the instructions on the notices.
- (11) After work on the supplemental restraint system is completed, check the SRS warning light (See page 05–690).



(b) SPIRAL CABLE (in Combination Switch)

(1) The steering wheel must be fitted correctly to the steering column with the spiral cable at the neutral position, otherwise cable disconnection and other troubles may occur. Refer to page 60–25 on this manual concerning the correct installation of the steering wheel.

(c) HORN BUTTON ASSEMBLY (with Airbag)

- (1) When removing the horn button assembly or handling a new horn button, it should be placed with the pad top surface facing upward. Placing it with the pad surface facing downward may lead to a serious accident if the airbag accedentally inflates. Also, do not place the horn button on top of one another.
- (2) Never measure the resistance of the airbag squib (This may cause the airbag to inflate, which is very dangerous).
- (3) Grease should not be applied to the horn button assembly, and the pad should not be cleaned with detergents of any kinds.
- (4) Store the horn button assembly where the ambient temperature remains below 93°C (200°F), without high humidity and away from electrical noise.
- (5) When using electric welding, first disconnect the airbag connector (2 yellow pins) under the steering column near the combination switch connector before starting work.

When disposing of the vehicle or the horn button assembly alone, the airbag should be deployed using an SST before disposal (See page 60–17).
 Perform the operation in a safe place away from electrical noise.



(d) INSTRUMENT PANEL PASSENGER AIRBAG ASSEMBLY

- (1) Always store a removed or new instrument panel passenger airbag assembly with the airbag inflation direction facing upward. Placing the airbag assembly with the airbag inflation direction facing downward could cause a serious accident if the airbag inflates.
- (2) Never measure the resistance of the airbag squib (This may cause the airbag to inflate, which is very dangerous).
- (3) Grease should not be applied to the instrument panel passenger airbag assembly, and the airbag door should not be cleaned with detergents of any kind.
- (4) Store the airbag assembly where the ambient temperature remains below 93°C (200°F), without high humidity and away from electrical noise.
- (5) When using electric welding, first disconnect the airbag connector (2 yellow pins) installed on the assembly before starting work.
- When disposing of a vehicle or the airbag assembly alone, the airbag should be deployed using an SST before disposal (See page 60–34).

Perform the operation in a safe place away from electrical noise.



2002 CAMRY REPAIR MANUAL (RM881U)

R05643 R06953 R06952

Date :

11

Z13950



- (e) FRONT SEAT AIRBAG ASSEMBLY
 - (1) Always store a removed or new front seat airbag assembly with the airbag inflation direction facing upward. Placing the airbag assembly with the airbag inflation direction facing downward could cause a serious accident if the airbag inflates.
 - (2) Never measure the resistance of the airbag squib (This may cause the airbag to inflate, which is very dangerous).
 - (3) Grease should not be applied to the front seat airbag assembly, and the airbag door should not be cleaned with detergents of any kind.
 - (4) Store the airbag assembly where the ambient temperature remains below 93°C (200°F), without high humidity and away from electrical noise.
 - (5) When using electric welding, first disconnect the airbag connector (2 yellow pins) installed on the assembly before starting work.
 - (6) When disposing of a vehicle or the side airbag assembly alone, the airbag should be deployed using an SST before disposal (See page 60–50).

Perform the operation in a safe place away from electrical noise.





(f) CURTAIN SHIELD AIRBAG ASSEMBLY

(1) Always store the removed or new curtain shield airbag assembly in a clear plastic bag, and keep it in a safe place.

NOTICE:

Protection bag is not re-useable.

CAUTION:

Never disassemble the curtain shield airbag assembly.

- (2) Never measure the resistance of the airbag squib (This may cause the airbag to inflate, which is very dangerous).
- (3) Grease should not be attached to the curtain shield airbag assembly, and the surface should not be cleared with detergents of any kind.
- (4) Store the airbag assembly where the ambient temperature remains below 93 °C (200 °F), without high humidity and away from electrical noise.
- (5) When using electric welding, first disconnect the airbag connector (2 yellow 2 pins) into the instrument panel before starting work.
- (6) When disposing of a vehicle or the curtain shield airbag assembly alone, the airbag should be deployed using an SST before disposal (See page 60–44). Perform the operation in a safe place away from electrical noise.





01–14

(g) SEAT BELT PRETENSIONER

- (1) Never measure the resistance of the seat belt pretensioner (This may cause the seat belt pretensioner to activate, which is very dangerous).
- (2) Never disassemble the seat belt pretensioner.
- (3) Never install the seat belt pretensioner to another vehicle.
- (4) Store the seat belt pretensioner where the ambient temperature remains below 80°C (176°F) without high humidity and away from electrical noise.
- (5) When using electric welding, first disconnect the connector (2 yellow pins) before starting work.
- (6) When disposing of a vehicle or the seat belt pretensioner alone, the seat belt pretensioner should be activated before disposal (See page 61–9). Perform the operation in a safe place away from electrical noise.
- (7) The seat belt pretensioner is hot after activation, so let it cool down sufficiently before disposal. Never apply water to cool down the seat belt pretensioner.
- (8) Oil or water should not be put on the front seat outer belt, and the front seat outer belt should not be cleaned with detergents of any kind.



- (h) AIRBAG SENSOR ASSEMBLY
 - (1) Never reuse the airbag sensor assembly involved in a collision where the SRS has deployed.
 - (2) The connectors to the airbag sensor assembly should be connected or disconnected with the sensor mounted on the floor. If the connectors are connected or disconnected while the airbag sensor assembly is not mounted to the floor, it could cause an undesired ignition of the supplemental restraint system.
 - (3) Work must be started after 90 seconds from the time the ignition switch is turned to the "LOCK" position and the negative (–) terminal cable is disconnected from the battery, even if only loosening the set bolts of the airbag sensor assembly.
- (i) WIRE HARNESS AND CONNECTOR
 - (1) The SRS wire harness is integrated with the instrument panel wire harness assembly. All the connectors in the system are in a standard yellow color. If the SRS wire harness becomes disconnected or the connector becomes broken due to an accident, etc., repair or replace it.





ELECTRONIC CONTROL

- REMOVAL AND INSTALLATION OF BATTERY TERMI-NAL
 - Before performing electrical work, disconnect the battery negative (-) terminal cable beforehand so as to prevent burnt-out damage by short.
 - (2) When disconnecting and installing the terminal cable, turn the ignition switch and lighting switch OFF, and loosen the terminal nut completely. Perform these operations without twisting or prying the terminal.
 - (3) When the battery terminal is removed, all the memories of the clock, radio, DTCs, etc. will be erased. So before removing it, check them and note them down.
 - When the battery terminal is disconnected, the sliding roof position memory is erased.
 Make sure to reset the sliding roof zero point See page 74–78.

b) HANDLING OF ELECTRONIC PARTS

- (1) Do not open the cover or case of the ECU unless absolutely necessary (If the IC terminals are touched, the IC may be destroyed by static electricity).
- (2) To disconnect electronic connectors, pull the connector itself, not the wires.
- (3) Be careful not to drop electronic components, such as sensors or relays. If they are dropped on a hard floor, they should be replaced and not be reused.
- (4) When cleaning the engine with steam, protect the electronic components, air filter and emission–related components from water.
- (5) Never use an impact wrench to remove or install temperature switches or temperature sensors.
- (6) When checking the continuity at the wire connector, insert the tester probe carefully to prevent terminals from bending.

4. REMOVAL AND INSTALLATION OF FUEL CONTROL PARTS

- (a) PLACE FOR REMOVING AND INSTALLING OF FUEL SYSTEM PARTS
 - (1) Work in a place with good air ventilation and without anything flammable such as welder, grinder, drill, electric motor or stove in the surroundings.
 - (2) Never work in a place such as a pit or nearby a pit, as there is a possibility that vaporized fuel is filled in those places.

01–16

(b) REMOVING AND INSTALLING OF FUEL SYSTEM PARTS

- (1) Prepare a fire extinguisher before starting the operation.
- (2) For prevention of the static electricity, install a ground on the fuel changer, vehicle and fuel tank, and do not spray much water so as to prevent slipping.
- (3) Never use any electric equipment like an electric motor or a working light as they may cause sparks or high temperature.
- (4) Never use an iron hammer, as it may cause sparks.
- (5) Dispose of the shop rag separately from any fuel deposit.







5. REMOVAL AND INSTALLATION OF ENGINE INTAKE PARTS

- (a) If any metal tip is mixed in the inlet pass, that may give a bad effect to the engine and turbocharger.
- (b) When removing and installing the inlet system parts, close the opening of the removed inlet system parts and the engine with a clean shop rag or gummed tape.
- (c) When installing the inlet system parts, check that there is no mixing of a metal tip.

HANDLING OF HOSE CLAMPS

- (a) Before removing the hose, check the clamp position to restore it securely.
- (b) Change a deformed or dented clamp into a new one.
- (c) In case of reusing the hose, install the clamp on the hose where it has a clamp track.
- (d) For a spring type clamp, make adjustment by adding force to the arrow mark direction after the installation.

7. FOR VEHICLES EQUIPPED WITH MOBILE COMMU-NICATION SYSTEM

- (a) Install an antenna as far as possible away from the ECU and sensors of the vehicle's electronic systems.
- (b) Install an antenna feeder at least 20 cm (7.87 in.) away from the ECU and sensors of the vehicle's electronic systems. For details of the ECU and sensors locations, refer to the section on the applicable component.
- (c) Prevent the antenna feeder from getting entangled with the other wirings, and keep the antenna feeder separately from the other wirings as much as possible.
- (d) Check that the antenna and feeder are correctly adjusted.
- (e) Do not install any powerful mobile communication system.

8. FOR VEHICLES EQUIPPED WITH TRACTION CONTROL (TRAC) SYSTEM

(a) NOTICES WHEN USING 2-WHEEL DRUM TESTER

(1) When using a 2-wheel drum tester such as a speedometer tester, a combination tester of speedometer and brake, chassis dynamometer or else, always turn the TRAC system off via the TRAC OFF switch before measurement.

NOTICE:

TRAC system OFF condition can be confirmed by the indication, "TRAC OFF" of the warning light in the combination meter.



FOR VEHICLES EQUIPPED WITH VEHICLE SKID CONTROL (VSC) SYSTEM

- (a) NOTICES WHEN USING DRUM TESTER
 - (1) When using a drum tester, be sure to start the engine with the ignition OFF, and connect SST to the terminals TS and CG of the DLC3 before measurement in order to prohibit the VSC operation.
 - SST 09843-18040

NOTICE:

- Confirm that the VSC warning light blinks.
- VSC system will be reset when the engine is restarted.
- Fasten the vehicle with lock chains.
- (b) NOTICES OF RELATED OPERATIONS TO VSC
 - Do not carry out unnecessary installation and removal, because it might disorder the adjustment of related parts to VSC.
 - (2) Be sure to carry out the preparation for operation and the confirmation of operation completion, in accordance with the instruction of the text, when the related operations to VSC are performed.

10. FOR VEHICLES EQUIPPED WITH CATALYTIC CONVERTER

CAUTION:

If large amount of unburned gasoline flows into the converter, it may cause overheating and a fire hazard. To prevent this, observe the following precautions.

- (a) Use only unleaded gasoline.
- (b) Avoid prolonged idling.

Avoid running the engine at idle speed for more than 20 minutes.

- (c) Avoid a spark jump test.
 - (1) Perform a spark jump test only when absolutely necessary. Perform this test as rapidly as possible.
 - (2) While testing, never race the engine.
- (d) Avoid a prolonged engine compression measurement.
 - Engine compression measurements must be performed as rapidly as possible.
- (e) Do not run the engine when the fuel tank is nearly empty. This may cause the engine to misfire and create an extra load on the converter.

2002 CAMRY REPAIR MANUAL (RM881U)

Date :

01–17

VEHICLE LIFT AND SUPPORT LOCATIONS

1. NOTICE ABOUT VEHICLE CONDITION WHEN JACKING UP

- (a) As a rule, the vehicle must be unloaded when jacking up. Never jack up or lift up the vehicle loaded with things of heavy weight.
- (b) When removing any parts of heavy weight like the engine and transmission, the center of gravity of the vehicle moves. Place a balance weight so as to keep it from rolling, or hold the jacking support location using the mission jack.

2. NOTICE FOR USING 4 POST LIFT

- (a) Follow the instruction manual for a safety operation.
- (b) Do not damage tires or wheels with a free wheel beam.
- (c) Using a wheel stopper, fix the vehicle.

3. NOTICE FOR USING JACK AND SAFETY STAND

(a) Work in the flat place using a wheel stopper at all times.



- (b) Use a safety stand with a rubber attachment, as shown in the illustration.
- (c) Support the specified location with the jack and safety stand accurately.
- (d) When jacking up the front wheels, release the parking brake and place wheel stoppers only behind the rear wheels. When jacking up the rear wheels, place wheel stoppers only in front of the front wheels.

Do not work or leave the vehicle supported only by a jack. Be sure to support the vehicle with a safety stand.

- (f) When jacking up only the front wheels or only the rear wheels, place wheel stoppers to both sides of the wheels that contact ground.
- (g) When jacking down the vehicle with its front wheels jacked up, release the parking brake and place wheel stoppers only in front of the rear wheels. When jacking down the vehicle with its rear wheels jacked up, place wheel stoppers only behind the front wheels.



01043-02

4. NOTICE FOR USING SWING ARM TYPE LIFT

- (a) Follow the instruction manual of the lift for a safe operation.
- (b) Use a cradle with a rubber attachment, as shown in the illustration.
- (c) Set in the vehicle so as to make its center of gravity as close as possible to the center of the lift. ("L" becomes short.)
- (d) place the vehicle horizontally by adjusting the height of the cradle, and match the groove of the cradle and the safety stand support location accurately.
- (e) Be sure to lock the swing arm during the operation.
- (f) Lift the vehicle up until the tires float, and shake the vehicle to make sure that the vehicle is stable.

5. NOTICE FOR USING PLATE TYPE LIFT

- (a) Follow the instruction manual of the lift for a safe operation.
- (b) Use a plate lift attachment.
- (c) Be sure to set the vehicle to the specified position.

Right and left set position	Place the vehicle over the center of the lift.
Front and roor act position	• Align the cushion gum ends of the plate with the attachment lower ends (A and C).
From and real set position	 Align the attachment upper end (B) with the rocker flange front side notch.

(d) Lift the vehicle up until the tires float a bit, and shake the vehicle to make sure that the vehicle is stable.



HOW TO TROUBLESHOOT ECU CONTROLLED SYSTEMS 01044-02 **GENERAL INFORMATION**

A large number of ECU controlled systems are used in CAMRY. In general, the ECU controlled system is considered to be a very intricate system requiring high level of technical knowledge and expert skill to troubleshoot. The fact is, however, that if you proceed to inspect the circuits one by one, troubleshooting of these systems is not complex. If you have adequate understanding of the system and basic knowledge of electricity, accurate diagnosis and necessary repair can be performed to locate and fix the problem. This manual is designed through emphasis of the above standpoint to help service technicians perform an accurate and effective troubleshooting, and is compiled for the following major ECU controlled systems.

The troubleshooting procedure and how to make use of it are described on the following pages.

System	Page
1. SFI System (2AZ–FE)	05–1
2. SFI System (1MZ–FE)	05–173
3. ABS with EBD System (BOSCH made)	05–360
4. ABS with EBD System (DENSO made)	05–401
5. ABS with EBD & BA & TRAC & VSC System	05–448
6. Electronic Controlled Automatic Transmission [ECT]	05–548
7. Air Conditioning System	05–616
8. Supplemental Restraint System	05–687
9. Lighting System	05–896
10.Audio System	05–928
11.Navigation System	05–991
12.Combination Meter	05–1070
13.Power Door Lock Control System	05–1132
14.Wireless Door Lock Control System	05–1148
15.Engine Immobiliser System	05–1165
16.Theft Deterrent System	05–1182
17.Body Multiplex Communication System	05–1196
18.Cruise Control System	05–1209
19.Power Window Control System	05–1239

FOR USING OBDII SCAN TOOL OR HAND-HELD TESTER

HINT:

- Before using the scan tool or tester, the scan tool's instruction book or tester's operator manual should be read thoroughly.
- If the scan tool or tester cannot communicate with the ECU controlled systems when you have connected the cable of the tester to the DLC3 with the ignition switch and tester turned ON, there is a problem on the vehicle side or tester side.
 - If the communication is normal when the tester is connected to another vehicle, inspect the diag-(1) nosis data link line (Bus⊕line) or ECU power circuit of the vehicle.
 - If the communication is still impossible when the tester is connected to another vehicle, the prob-(2) lem is probably in the tester itself, so perform the Self Test procedures outlined in the Tester Operator's Manual.

HOW TO PROCEED WITH TROUBLESHOOTING

HINT:

Carry out a troubleshooting in accordance with the procedure on the following page. Here, only the basic procedure is shown. Details are provided in the Diagnostics section, showing the most effective methods for each circuit. Confirm the troubleshooting procedures first for the relevant circuit before beginning the troubleshooting of that circuit.

1 Vehicle brought to workshop 2 Customer problem analysis (a) Ask the customer about the conditions and environment when the problem occurred. 3 Symptom confirmation and DTC (and freeze frame data) check (a) Check the battery positive voltage. Voltage: 10 - 14 V (Engine stopped) (b) Visually check the wire harness, connectors and fuses for open and short, etc. (c) Warm up the engine to the normal operating temperature. (d) Confirm the problem symptoms and conditions, and check the DTCs according to the applicable chart. OK Go to step 5 NG 4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (b) Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4.	
2 Customer problem analysis (a) Ask the customer about the conditions and environment when the problem occurred. 3 Symptom confirmation and DTC (and freeze frame data) check (a) Check the battery positive voltage. Voltage: 10 – 14 V (Engine stopped) (b) Visually check the wire harness, connectors and fuses for open and short, etc. (c) Warm up the engine to the normal operating temperature. (d) Confirm the problem symptoms and conditions, and check the DTCs according to the applicable chart. OK Go to step 5 NG Image: State of the system of the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (b) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. (a) Check the results obtained in step 4. (b) Confirm the circuit for the system or the pa	1 Vehicle brought to workshop
2 Customer problem analysis (a) Ask the customer about the conditions and environment when the problem occurred. 3 Symptom confirmation and DTC (and freeze frame data) check (a) Check the battery positive voltage. Voltage: 10 – 14 V (Engine stopped) (b) Visually check the wire harness, connectors and fuses for open and short, etc. (c) Warm up the engine to the normal operating temperature. (d) Confirm the problem symptoms and conditions, and check the DTCs according to the applicable chart. OK Go to step 5 NG 4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (b) Circuit inspection or parts inspection (c) Confirm the circuit for t	
2 Customer problem analysis (a) Ask the customer about the conditions and environment when the problem occurred. 3 Symptom confirmation and DTC (and freeze frame data) check (a) Check the battery positive voltage. Voltage: 10 - 14 V (Engine stopped) (b) Visually check the wire harness, connectors and fuses for open and short, etc. (c) Warm up the engine to the normal operating temperature. (d) Confirm the problem symptoms and conditions, and check the DTCs according to the applicable chart. OK Go to step 5 NG Image: Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (b) Confirm the circuit for the s	
 (a) Ask the customer about the conditions and environment when the problem occurred. 3 Symptom confirmation and DTC (and freeze frame data) check (a) Check the battery positive voltage. Voltage: 10 – 14 V (Engine stopped) (b) Visually check the wire harness, connectors and fuses for open and short, etc. (c) Warm up the engine to the normal operating temperature. (d) Confirm the problem symptoms and conditions, and check the DTCs according to the applicable chart. OK Go to step 5 NG 4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 5 Problem symptoms chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. 7 Repair 	2 Customer problem analysis
 3 Symptom confirmation and DTC (and freeze frame data) check (a) Check the battery positive voltage. Voltage: 10 - 14 V (Engine stopped) (b) Visually check the wire harness, connectors and fuses for open and short, etc. (c) Warm up the engine to the normal operating temperature. (d) Confirm the problem symptoms and conditions, and check the DTCs according to the applicable chart. OK Go to step 5 NG 4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. 7 Repair 	(a) Ask the customer about the conditions and environment when the problem occurred
 3 Symptom confirmation and DTC (and freeze frame data) check (a) Check the battery positive voltage. Voltage: 10 - 14 V (Engine stopped) (b) Visually check the wire harness, connectors and fuses for open and short, etc. (c) Warm up the engine to the normal operating temperature. (d) Confirm the problem symptoms and conditions, and check the DTCs according to the applicable chart. OK Go to step 5 NG 4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (b) Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. (b) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. (c) 7 Repair 	
 3 Symptom confirmation and DTC (and freeze frame data) check (a) Check the battery positive voltage. Voltage: 10 - 14 V (Engine stopped) (b) Visually check the wire harness, connectors and fuses for open and short, etc. (c) Warm up the engine to the normal operating temperature. (d) Confirm the problem symptoms and conditions, and check the DTCs according to the applicable chart. OK Go to step 5 NG 4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (b) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (b) Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. (b) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. (b) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. (c) 7 Repair	
 (a) Check the battery positive voltage. Voltage: 10 - 14 V (Engine stopped) (b) Visually check the wire harness, connectors and fuses for open and short, etc. (c) Warm up the engine to the normal operating temperature. (d) Confirm the problem symptoms and conditions, and check the DTCs according to the applicable chart. OK Go to step 5 NG 4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (b) Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. (b) The part of the part which should be checked using the problem symptoms table. (c) The part of the part which should be checked using the problem symptoms table. 	3 Symptom confirmation and DTC (and freeze frame data) check
 (a) Voltage: 10 - 14 V (Engine stopped) (b) Visually check the wire harness, connectors and fuses for open and short, etc. (c) Warm up the engine to the normal operating temperature. (d) Confirm the problem symptoms and conditions, and check the DTCs according to the applicable chart. OK Go to step 5 NG 4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (b) Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. (b) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. (c) 7 Repair 	(a) Check the battery positive voltage
 (b) Visually check the wire harness, connectors and fuses for open and short, etc. (c) Warm up the engine to the normal operating temperature. (d) Confirm the problem symptoms and conditions, and check the DTCs according to the applicable chart. OK Go to step 5 NG 4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. (b) Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. (b) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. (b) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. (b) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. (c) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. (c) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. (c) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. (c)	Voltage: 10 – 14 V (Engine stopped)
 (c) Warm up the engine to the normal operating temperature. (d) Confirm the problem symptoms and conditions, and check the DTCs according to the applicable chart. OK Go to step 5 NG 4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. Go to step 6 5 Problem symptoms chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. 7 Repair 	(b) Visually check the wire harness, connectors and fuses for open and short, etc.
 (d) Confirm the problem symptoms and conditions, and check the DTCs according to the applicable chart. OK Go to step 5 NG 4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. Go to step 6 5 Problem symptoms chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the pTC chart. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. 7 Repair 	(c) Warm up the engine to the normal operating temperature.
OK Go to step 5 NG 4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. Go to step 6 5 Problem symptoms chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. 7 Repair	(d) Confirm the problem symptoms and conditions, and check the DTCs according to the applicable ch
NG 4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. Go to step 6 5 Problem symptoms chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. 7 Repair	OK Go to step 5
NG 4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. Go to step 6 5 Problem symptoms chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. 7 Repair	
4 DTC chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. Go to step 6 5 Problem symptoms chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. 7 Repair	NG
 (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. Go to step 6 5 Problem symptoms chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. 7 Repair 	4 DTC chart
 (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the DTC chart. Go to step 6 5 Problem symptoms chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. 	
Go to step 6 5 Problem symptoms chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table. 7 Repair	(a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the p
Go to step 6 5 Problem symptoms chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. 7 Repair	which should be checked using the DTC chart.
5 Problem symptoms chart (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. 7 Repair	Go to step 6
 (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. 7 Repair 	5 Problem symptoms chart
 (a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the part which should be checked using the problem symptoms table. 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. 7 Repair 	
 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. 7 Repair 	(a) Check the results obtained in step 3, then confirm the inspection procedure for the system or the p
6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. 7 Repair	which should be checked using the problem symptoms table.
 6 Circuit inspection or parts inspection (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. 7 Repair 	
 (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. 7 Repair 	6 Circuit inspection or parts inspection
 (a) Confirm the circuit for the system or the part which should be checked using the problem symptoms table or the results obtained in step 4. 7 Repair 	
T Repair	(a) Confirm the circuit for the system or the part which should be checked using the problem sympto
7 Repair	table of the results obtained in step 4.
7 Repair	
	7 Repair
7 Repair	 (a) Confirm the circuit for the system or the part which should be checked using the problem sympto table or the results obtained in step 4.

(a) Repair the affected system or part in accordance with the instructions in step 6.

21

Date :

01045-02

	_					
8	3	Confirmation test				
(a)	 (a) After completing repairs, confirm that the problem has been solved. (If the problem dose not reoccur, perform a confirmation test under the same conditions and in the same environment as when it occurred for the first time.) 					
	_					
EN	١D					

CUSTOMER PROBLEM ANALYSIS

HINT:

- In troubleshooting, the problem symptoms must be confirmed accurately and all preconceptions must be cleared in order to give an accurate judgment. To ascertain what the problem symptoms are, it is extremely important to ask the customer about the problem and conditions when it occurred.
- The following 5 items are important points in the problem analysis. Past problems which are thought to be unrelated and the repair history, etc. may also help in some cases. So, as much information as possible should be gathered and its relationship with the problem symptoms should be correctly ascertained for a reference in troubleshooting. A customer problem analysis table is provided in Diagnostics section for each system for your use.

— Important Points in the Customer Problem Analysis -

- What ------ Vehicle model, system name
- When ——— Date, time, occurrence frequency
- Where —— Road conditions
- Under what conditions? —— Running conditions, driving conditions, weather conditions
- How did it happen? —— Problem symptoms

(Sample) Supplemental restraint system check sheet.

CUSTOMER PROBLEM ANALYSIS CHECK								
Supplemental Restraint System Check Sheet Inspector's Name								
	Registration No.		lo.					
Customer's Name			Registration Year Frame No.			/	/	
Date Vehicle Brought In	/	/	Odometer Rea	lding				km miles
Date Problem First Occurre	d					/	/	
Weather	□ Fine		🗆 Rainy		nowy	C Other		
Temperature	Approx.							
Vehicle Operation	☐ Starting ☐ Driving	□ [□ Const □ Other] Idling ant speed		eration	🗆 Dec	eleratio	n]
					\supset			
					-			

SYMPTOM CONFIRMATION AND DIAGNOSTIC TROUBLE CODE

HINT:

 The diagnostic system in CAMRY has various functions. The first function is the Diagnostic Trouble Code (DTC) Check in which a malfunction in the signal circuits to the ECU is stored in code form in the ECU memory. Another function is the Input Signal Check which checks if the signals from various switches are sent to the ECU correctly. By using these check functions, possible areas of the problem can be narrowed down quickly and troubleshooting can be performed effectively. Diagnostic functions are incorporated in the following systems in CAMRY.

System	Diagnostic Trouble Code Check	Input Signal Check (Sensor Check)	Diagnostic Test Mode (Active Test)
SFI System	لاً (with Check Mode)	Ł	Z
ABS with EBD System	S	S	Ś
ABS with EBD & BA & TRAC & VSC System	Ś	N	Ś
Electronic Controlled Automatic Transmission [ECT]	لکا (with Check Mode)	Ŀ	
Air Conditioning System	Ś	Ś	
Supplement Restraint System	Ś		
Power Door Lock Control System	5		
Wireless Door Lock Control System	Ś		
Engine Immobiliser System	Ś		
Body Multiplex Communication System	Ś		
Cruise Control System	Ĺ	Ż	

In the DTC check, it is very important to determine whether the problem indicated by the DTC is still occurring or has occurred in the past but returned to normal at present. In addition, it must be checked in the problem symptom check whether the malfunction indicated by the DTC is directly related to the problem symptom or not. For this reason, the DTC should be checked before and after the symptom confirmation to determine the current conditions. If this is not done, it may, depending on the case, result in an unnecessary troubleshooting for normally operating systems, making it more difficult to detect the problem area, or trying to repair irrelevant areas. Therefore always follow the procedure in the correct order and perform the DTC check.

A flow chart showing how to proceed with the troubleshooting using the diagnostic trouble code (DTC) check is shown below. This flow chart shows how to utilize the DTC check effectively Then, by carefully checking the results, indicates how to proceed either to the DTC troubleshooting or to the troubleshooting of problem symptoms table.

I DTC check	Ĺ
-------------	---

2

3

Making a note and clearing of the DTCs displayed

Symptom confirmation

Ľ	Problem symptoms exist
Ŀ	No problem symptoms exist
a Go to step 5	

b	7		
4	Simulation test using the s	ymptom simulation methods	
5	DTC check		
i			
		Z	DTC displayed
		<u></u>	Normal code displayed
		a Troubleshooting o	f problem indicated by DTC
b 6	Symptom confirmation		
		Z	No problem symptoms exist
		Ľ	Problem symptoms exist
		If a DTC is displayed in the initial DTC check, it indicates that a trouble may have occurred in a wire harness or connector in	
		that circuit in the past, therefore check the wire harness and connectors (See page $01-31$).	
		a System normal	
b			
Trou	bleshooting of each problem sy	mptom	

The problem is still occurring in a place other than the diagnostic circuit (The DTC displayed first is either for a past problem or it is a secondary problem).

01–25

SYMPTOM SIMULATION

HINT:

The most difficult case in troubleshooting is when no problem symptoms occurs. In such cases, a thorough customer problem analysis must be carried out, Then simulate the same or similar conditions and environment in which the problem occurred in the customer's vehicle. No matter how much experience a technician has, or how skilled he may be, if he proceeds to troubleshoot without confirming the problem symptoms, he will tend to overlook something important in the repair operation and make a wrong guess somewhere, which will only lead to a standstill. For example, for a problem which only occurs when the engine is cold, or for a problem which occurs due to vibration caused by the road during driving, etc., the problem can never be determined with the engine hot condition or the vehicle at a standstill. Since vibration, heat or water penetration (moisture) is a likely cause for the problem which is difficult to reproduce, the symptom simulation tests introduced here are effective measures in a point that the external causes are applied to the vehicle in a stationary condition.

Important points in the symptom simulation test:

In the symptom simulation test, the problem symptoms should be confirmed, and the problem area or parts must also be found out. To do so, narrow down the possible problem circuits according to the symptoms before starting this test and have a hand-held tester connected beforehand. After that, carry out the symptom simulation test, judging whether the circuit being tested is defective or normal and also confirming the problem symptoms at the same time. Refer to the problem symptoms table of each system to narrow down the possible causes of the symptom.





1. VIBRATION METHOD: When vibration seems to be the major cause.

- (a) PART AND SENSOR
 - (1) Apply slight vibration with a finger to the part of the sensor considered to be the problem cause and check that the malfunction occurs.

HINT:

Applying strong vibration to relays may result in open relays.

- (b) CONNECTORS
 - (1) Slightly shake the connector vertically and horizontally.
- (c) WIRE HARNESS
 - (1) Slightly shake the wire harness vertically and horizontally.

The connector joint and fulcrum of the vibration are the major areas to be checked thoroughly.

- 2. HEAT METHOD: When the problem seems to occur when the suspect area is heated.
- (a) Heat the component that is the possible cause of the malfunction with a hair dryer or similar object. Check if the malfunction occurs.

NOTICE:

- Do not heat to more than 60°C (140°F) (Temperature is limited so as not to damage the components).
- Do not apply heat directly to the parts in the ECU.

2002 CAMRY REPAIR MANUAL (RM881U)



- 3. WATER SPRINKLING METHOD: When the malfunction seems to occur on a rainy day or in a high-humidity condition.
- (a) Sprinkle water onto the vehicle and check if the malfunction occurs.

NOTICE:

- Never sprinkle water directly onto the engine compartment, but indirectly change the temperature and humidity by applying water spray onto the radiator front surface.
- Never apply water directly onto the electronic components.

HINT:

If a vehicle is subject to water leakage, the leaked water may contaminate the ECU. When testing a vehicle with a water leakage problem, special caution must be taken.



4. OTHERS: When the malfunction seems to occur when electrical load is excessive.

(a) Turn on all the electrical loads including the heater blower, headlights, rear window defogger, etc., and check if the malfunction occurs.

DIAGNOSTIC TROUBLE CODE CHART

The inspection procedure is shown in the table below. This table permits an efficient and accurate troubleshooting using the diagnostic trouble codes displayed in the diagnostic trouble code check. Proceed with troubleshooting in accordance with the inspection procedure given in the diagnostic chart corresponding to the diagnostic trouble codes displayed. The Supplemental Restraint System diagnostic trouble code chart is shown below as an example.



PROBLEM SYMPTOMS TABLE

The suspected circuits or parts for each problem symptom are shown in the table below. Use this table to troubleshoot the problem when a "Normal" code is displayed in the diagnostic trouble code check but the problem is still occurring. Numbers in the table indicate the inspection order in which the circuits or parts should be checked.

HINT:

When the problem is not detected by the diagnostic system even though the problem symptom is present, it is considered that the problem is occurring outside the detection range of the diagnostic system, or that the problem is occurring in a system other than the diagnostic system.

	 Page Indicates the page where the flow chart for is located. 	each circuit	
• Circuit Inspection, Inspection Order Indicates the circuit which needs to be checked fo symptom. Check in the order indicated by the nu	r each problem umbers.		
Problem Symptom Circuit or Part Name Indicates the circuit or part which needs to be checked.			
PROBLEM SYMPTOMS TABLE Proceed with troubleshooting of each circuit in the table below.			
Symptom	Suspected Area	See page	
 With the ignition switch in ACC or ON position, the SRS warning light sometimes lights up after approx. 6 seconds have elapsed. SRS warning light is always lit up even when ignition switch is in the LOCK position 	1. SRS warning light circuit (Always lights up when ignition switch is in LOCK position.)	05–180	
 With the ignition switch in the ACC or ON position, the SRS warning light does not light up. 	1. SRS warning light circuit (Does not light up when ignition switch is turned to ACC or ON.)	05–183	
 DTC is not displayed. SRS warning light is always lit up at the time of DTC check procedure. DTC is displayed without Tc and CG terminal connection. 	1. Tc terminal circuit	05–187	
	1		

CIRCUIT INSPECTION

How to read and use each page is shown below.



ELECTRONIC CIRCUIT INSPECTION PROCEDURE

1. **BASIC INSPECTION**

- **RESISTANCE MEASURING CONDITION OF ELECTRONIC PARTS** (a)
 - Unless stated, all resistance is measured at an ambient temperature of 20°C (68°F). Because (1) the resistance may be outside the specifications if measured at high temperatures immediately after the vehicle has been running, measurements should be made when the engine has cooled down.



Looseness of Crimping Core Wire Terminal Deformation Pull Lightly D25087

HANDLING OF CONNECTOR

- (1) When removing the connector with a lock, press the connector toward the engagement and remove the lock by making the lock claw movable easily.
- When removing the connector, do not hold the har-(2) ness, but hold the connector.
- (3) Before connecting the connector, check that there are no deformation, damage and missing of the terminals.
- (4) Connection of the connector with a lock should be securely done until it makes a click sound.
- In case of checking the connector with a Toyota (5) electrical tester, perform it at the back side (harness side) of the connector using a mini test lead.

NOTICE:

- As a water proof connector cannot be checked from its back side, check by connecting the sub-harness.
- Do not damage the terminals by moving the inserted tester needle.
- (c) CONNECTOR CHECKING POINTS
 - Checking when the connector is connected: (1) By holding the connector, check the inserted condition and locking efficiency (engaged condition).
 - (2) Checking when the connector is removed: Check by pulling the wire harness lightly (missing terminal, terminal crimping condition, core wire break).

Check visually if there is any rust, metal tip, water and bend of terminal (rust, mixing of foreign object, terminal deformation).

NOTICE:

When testing a gold-plated female terminal, always use a gold-plated male terminal.

01046-02

INTRODUCTION - HOW TO TROUBLESHOOT ECU CONTROLLED SYSTEMS





 Checking of the contact pressure of the terminal: Prepare the same terminal as a male terminal. By inserting it to a female terminal, check the engaged condition and sliding load.

- REPAIR METHOD OF CONNECTOR TERMINAL
 - In case that there is any soil at the contact point, clean the contact point using an air gun or shop rag. At this time, never polish the contact point using a sand paper as the platings may come off.
 - (2) In case of abnormal contact pressure, replace the female terminal. At this time, if a male terminal is gold–plated (gold color), use gold–plated female terminals and if it is silver–plated (silver color), use silver–plated female terminals.



(e) HANDLING OF WIRE HARNESS

- In case of removing the wire harness, check the wiring and clamping condition before the work so as to is restore it correctly.
- (2) Never twist, pull or slack off the wire harness more than necessary.
- (3) Never make the wire harness come into contact with a high-temperature part, rotating, moving, vibrating or acute-angled part (edge of the panel, tip of the screw, etc.).
- (4) When installing parts, never sandwich the wire harness between them.
- (5) Never cut or break the cover of the wire harness. If it is cut or broken, replace it or securely repair it with a vinyl tape.

CHECK OPEN CIRCUIT

(a) For the open circuit in the wire harness in Fig. 1, perform "(b) Check the continuity" or "(c) Check the voltage" to locate the section.







- Check the continuity.
 - Disconnect connectors "A" and "C" and measure (1) the resistance between them.

Resistance: 1 Ω or less

Measure the resistance while lightly shaking the wire harness vertically and horizontally.

In the case of Fig. 2:

Between terminal 1 of connector "A" and terminal 1 of connector "C" \rightarrow No continuity (open)

Between terminal 2 of connector "A" and terminal 2 of connector "C" \rightarrow Continuity

Therefore, it is found out that there is an open circuit between terminal 1 of connector "A" and terminal 1 of connector "C".

Disconnect connector "B" and measure the resis-(2) tance between the connectors.

In the case of Fig. 3:

Between terminal 1 of connector "A" and terminal 1 of connector "B1" \rightarrow Continuity

Between terminal 1 of connector "B2" and terminal 1 of connector "C" \rightarrow No continuity (open)

Therefore, it is found out that there is an open circuit between terminal 1 of connector "B2" and terminal 1 of connector "C".

- Check the voltage. (c)
 - In a circuit in which voltage is applied (to the ECU (1) connector terminal), an open circuit can be checked by conducting a voltage check.

As shown in Fig. 4, with each connector still connected, measure the voltage between the body ground and terminal 1 of connector "A" at the ECU 5 V output terminal, terminal 1 of connector "B", and terminal 1 of connector "C", in that order.

(2) If the results are:

5 V: Between terminal 1 of connector "a" and body around

5 v: between terminal 1 of connector "b" and body around

0 v: between terminal 1 of connector "c" and body around

Then it is found out that there is an open circuit in the wire harness between terminal 1 of "B" and terminal 1 of "C".

HINT:

Fig. 6

BE4068

Sensor



R



(a) If the wire harness is ground shorted as in Fig. 5, locate the section by conducting a "continuity check with the body ground".

- (b) Check the continuity with the body ground.
 - (1) Disconnect connectors "A" and "C" and measure the resistance between terminal 1 and 2 of connector "A" and the body ground.

Resistance: 1 M Ω or higher

HINT:

ECU

Ž17009

ł

Measure the resistance while lightly shaking the wire harness vertically and horizontally.

In the case of Fig. 6:

Between terminal 1 of connector "A" and body ground \rightarrow Continuity (short)

Between terminal 2 of connector "A" and body ground \rightarrow No continuity

Therefore, it is found out that there is a short circuit between terminal 1 of connector "A" and terminal 1 of connector "C".



(2) Disconnect connector "B" and measure the resistance between terminal 1 of connector "A" and the body ground, and terminal 1 of connector "B2" and the body ground.

In the case of Fig. 7:

Between terminal 1 of connector "A" and body ground \rightarrow No continuity

Between terminal 1 of connector "B2" and body ground \rightarrow Continuity (short)

Therefore, it is found out that there is a short circuit between terminal 1 of connector "B2" and terminal 1 of connector "C".

4. CHECK AND REPLACE ECU

NOTICE:

- Start an inspection of the connector from the backside of the connector at the wire harness side with the connector connected to the ECU.
- When no measuring condition is specified, perform the inspection with the engine stopped and also the ignition switched ON.
- (a) First check the ECU ground circuit. If it is faulty, repair it. If it is normal, the ECU could be faulty So, replace the ECU with a normal functioning one and check if the symptoms appear.
- Example Ground Ground



(1) Measure the resistance between the ECU ground terminal and body ground. **Resistance: 1** Ω or less

(2) Disconnect the ECU connector, check the ground terminals on the ECU side and wire harness side for bend and check the contact pressure.

TERMS ABBREVIATIONS USED IN THIS MANUAL

01047–02

Abbreviations	Meaning
ABS	Anti–Lock Brake System
A/C	Air Conditioner
AC	Alternating Current
ACC	Accessory
ACIS	Acoustic Control Induction System
ACSD	Automatic Cold Start Device
A.D.D.	Automatic Disconnecting Differential
A/F	Air–Fuel Ratio
AHC	Active Height Control Suspension
ALR	Automatic Locking Retractor
ALT	Alternator
AMP	Amplifier
ANT	Antenna
APPROX.	Approximately
ASSY	Assembly
A/T, ATM	Automatic Transmission (Transaxle)
ATF	Automatic Transmission Fluid
AUTO	Automatic
AUX	Auxiliary
AVG	Average
AVS	Adaptive Variable Suspension
B+	Battery Voltage
ВА	Brake Assist
BACS	Boost Altitude Compensation System
BAT	Battery
BDC	Bottom Dead Center
B/L	Bi–Level
B/S	Bore-Stroke Ratio
BTDC	Before Top Dead Center
BVSV	Bimetallic Vacuum Switching Valve
Calif.	California
СВ	Circuit Breaker
CCo	Catalytic Converter For Oxidation
CD	Compact Disc
CF	Cornering Force
CG	Center Of Gravity
СН	Channel
СКД	Complete Knock Down
COMB.	Combination
CPE	Coupe
CPS	Combustion Pressure Sensor
CPU	Central Processing Unit
CRS	Child Restraint System
CTR	Center
C/V	Check Valve
CV	Control Valve
CW	Curb Weight
DC	Direct Current

2002 CAMRY REPAIR MANUAL (RM881U)

Abbreviations	Meaning
DEF	Defogger
DFL	Deflector
DIFF.	Differential
DIFF. LOCK	Differential Lock
D/INJ	Direct Injection
DLC	Data Link Connector
DLI	Distributorless Ignition
DOHC	Double Overhead Cam shaft
DP	Dash Pot
DS	Dead Soak
DSP	Digital Signal Processor
DTC	Diagnostic Trouble Code
DVD	Digital Versatible Disc
EBD	Electric Brake Force Distribution
ECAM	Engine Control And Measurement System
ECD	Electronic Controlled Diesel
ECDY	Eddy Current Dynamometer
ECT	Electronic Control Transmission
ECU	Electronic Control Unit
ED	Electro–Deposited Coating
EDU	Electronic Driving Unit
EDIC	Electric Diesel Injection Control
EFI	Electronic Fuel Injection
E/G	Engine
EGR	Exhaust Gas Recirculation
EGR-VM	EGR–Vacuum Modulator
ELR	Emergency Locking Retractor
EMPS	Electric Motor Power Steering
ENG	Engine
ESA	Electronic Spark Advance
ETCS-i	Electronic Throttle Control System–intelligent
EVAP	Evaporative Emission Control
EVP	Evaporator
E–VRV	Electric Vacuum Regulating Valve
EX	Exhaust
FE	Fuel Economy
FE	Front-Engine Front-Wheel-Drive
F/G	Fuel Gauge
FIPG	Formed In Place Gasket
FL	Fusible Link
F/P	Fuel Pump
FPU	Fuel Pressure Up
Fr	Front
FR	Front-Engine Rear-Wheel-Drive
F/W	Flywheel
FW/D	Flywheel Damper
FWD	Front-Wheel-Drive
GAS	Gasoline
GND	Ground
GPS	Global Positioning System
HAC	High Altitude Compensator
L	

2002 CAMRY REPAIR MANUAL (RM881U)

37

Abbreviations	Meaning
H/B	Hatchback
H-FUSE	High Current Fuse
н	High
HID	High Intensity Discharge (Head Lamp)
HSG	Housing
НТ	Hard Top
HWS	Heated Windshield System
IC	Integrated Circuit
IDI	Indirect Diesel Injection
IFS	Independent Front Suspension
IG	Ignition
IIA	Integrated Ignition Assembly
IN	Intake (Manifold, Valve)
INT	Intermittent
I/P	Instrument Panel
IRS	Independent Rear Suspension
ISC	Idle Speed Control
J/B	Junction Block
J/C	Junction Connector
KD	Kick–Down
LAN	Local Area Network
LB	Liftback
LCD	Liquid Crystal Display
LED	Light Emitting Diode
LH	Left-Hand
LHD	Left–Hand Drive
L/H/W	Length, Height, Width
LLC	Long–Life Coolant
LNG	Liquified Natural Gas
LO	Low
LPG	Liquified Petroleum Gas
LSD	Limited Slip Differential
LSP & PV	Load Sensing Proportioning And Bypass Valve
LSPV	Load Sensing Proportioning Valve
MAP	Manifold Absolute Pressure
MAX.	Maximum
MIC	Microphone
MIL	Malfunction Indicator Lamp
MIN.	Minimum
MG1	Motor Generator No.1
MG2	Motor Generator No.2
MP	Multipurpose
MPI	Multipoint Electronic Injection
MPX	Multiplex Communication System
M/T, MTM	Manual Transmission (Transaxle)
МТ	Mount
MTG	Mounting
N	Neutral
NA	Natural Aspiration
NO.	Number
O2S	Oxygen Sensor

2002 CAMRY REPAIR MANUAL (RM881U)

Abbreviations	Meaning
O/D	Overdrive
OEM	Original Equipment Manufacturing
OHC	Overhead Camshaft
OHV	Overhead Valve
OPT	Option
ORVR	On-board Refilling Vapor Recovery
O/S	Oversize
P & BV	Proportioning And Bypass Valve
PCS	Power Control System
PCV	Positive Crankcase Ventilation
РКВ	Parking Brake
PPS	Progressive Power Steering
PS	Power Steering
РТО	Power Take–Off
P/W	Power Window
R & P	Rack And Pinion
RAM	Random Access Memory
R/B	Relay Block
RBS	Recirculating Ball Type Steering
R/F	Reinforcement
RFS	Rigid Front Suspension
RH	Right-Hand
RHD	Right–Hand Drive
RLY	Relay
ROM	Read Only Memory
Rr	Rear
RR	Rear-Engine Rear-Wheel-Drive
RRS	Rigid Rear Suspension
RWD	Rear–Wheel–Drive
SDN	Sedan
SEN	Sensor
SICS	Starting Injection Control System
SOC	State Of Charge
SOHC	Single Overhead Camshaft
SPEC	Specification
SPI	Single Point Injection
SRS	Supplemental Restraint System
SSM	Special Service Materials
SST	Special Service Tools
STD	Standard
STJ	Cold–Start Fuel Injection
SW	Switch
SYS	System
T/A	Transaxle
ТАСН	Tachometer
ТВІ	Throttle Body Electronic Fuel Injection
тс	Turbocharger
TCCS	TOYOTA Computer–Controlled System
TCV	Timing Control Valve
TDC	Top Dead Center
TEMP	
	i i i posicile

Abbreviations	Meaning
TEMS	TOYOTA Electronic Modulated Suspension
TFT	Toyota Free–Tronic
TIS	Total Information System For Vehicle Development
T/M	Transmission
TMC	TOYOTA Motor Corporation
ТММК	TOYOTA Motor Manufacturing Kentucky, Inc.
TRAC	Traction Control System
TURBO	Turbocharge
TWC	Three–Way Catalyst
U/D	Underdrive
U/S	Undersize
VCV	Vacuum Control Valve
VENT	Ventilator
VIN	Vehicle Identification Number
VPS	Variable Power Steering
VSC	Vehicle Stability Control
VSV	Vacuum Switching Valve
VTV	Vacuum Transmitting Valve
VVT–i	Variable Valve Timing-intelligent
W/	With
WGN	Wagon
W/H	Wire Harness
W/O	Without
WU–TWC	Warm Up Three-way Catalytic Converter
WU–OC	Warm Up Oxidation Catalytic Converter
1ST	First
2ND	Second
2WD	Two Wheel Drive Vehicle (4 x 2)
3RD	Third
4TH	Fourth
4WD	Four Wheel Drive Vehicle (4 x 4)
4WS	Four Wheel Steering System
5TH	Fifth

GLOSSARY OF SAE AND TOYOTA TERMS

This glossary lists all SAE–J1930 terms and abbreviations used in this manual in compliance with SAE recommendations, as well as their TOYOTA equivalents.

SAE ABBREVIATIONS	SAE TERMS	TOYOTA TERMS ()—ABBREVIATIONS
A/C	Air Conditioning	Air Conditioner
ACL	Air Cleaner	Air Cleaner, A/CL
AIR	Secondary Air Injection	Air Injection (AI)
AP	Accelerator Pedal	-
B+	Battery Positive Voltage	+B, Battery Voltage
BARO	Barometric Pressure	HAC
CAC	Charge Air Cooler	Intercooler
CARB	Carburetor	Carburetor
CFI	Continuous Fuel Injection	-
СКР	Crankshaft Position	Crank Angle
CL	Closed Loop	Closed Loop
CMP	Camshaft Position	Cam Angle
CPP	Clutch Pedal Position	-
стох	Continuous Trap Oxidizer	-
CTP	Closed Throttle Position	LL ON, Idle ON
DFI	Direct Fuel Injection (Diesel)	Direct Injection (DI)
DI	Distributor Ignition	_
DLC1	Data Link Connector 1	1: Check Connector
DLC2	Data Link Connector 2	2: Total Diagnosis Communication Link (TDCL)
DLC3	Data Link Connector 3	3: OBD II Diagnostic Connector
DTC	Diagnostic Trouble Code	Diagnostic Trouble Code
DTM	Diagnostic Test Mode	-
ECL	Engine Control Level	-
ECM	Engine Control Module	Engine ECU (Electronic Control Unit)
ECT	Engine Coolant Temperature	Coolant Temperature, Water Temperature (THW)
EEPROM	Electrically Erasable Programmable Read Only Memory	Electrically Erasable Programmable Read Only Memory (EEPROM), Erasable Programmable Read Only Memory (EPROM)
EFE	Early Fuel Evaporation	Cold Mixture Heater (CMH), Heat Control Valve (HCV)
EGR	Exhaust Gas Recirculation	Exhaust Gas Recirculation (EGR)
EI	Electronic Ignition	TOYOTA Distributorless Ignition (TDI)
EM	Engine Modification	Engine Modification (EM)
EPROM	Erasable Programmable Read Only Memory	Programmable Read Only Memory (PROM)
EVAP	Evaporative Emission	Evaporative Emission Control (EVAP)
FC	Fan Control	_
FEEPROM	Flash Electrically Erasable Programmable Read Only Memory	_
FEPROM	Flash Erasable Programmable Read Only Memory	-
FF	Flexible Fuel	-
FP	Fuel Pump	Fuel Pump
GEN	Generator	Alternator
GND	Ground	Ground (GND)

2002 CAMRY REPAIR MANUAL (RM881U)

01048-02

HO2S	Heated Oxygen Sensor	Heated Oxygen Sensor (HO ₂ S)
IAC	Idle Air Control	Idle Speed Control (ISC)
IAT	Intake Air Temperature	Intake or Inlet Air Temperature
ICM	Ignition Control Module	_
IFI	Indirect Fuel Injection	Indirect Injection (IDL)
IFS	Inertia Fuel–Shutoff	-
ISC	Idle Speed Control	-
KS	Knock Sensor	Knock Sensor
MAF	Mass Air Flow	Air Flow Meter
MAP	Manifold Absolute Pressure	Manifold Pressure Intake Vacuum
MC	Mixture Control	Electric Bleed Air Control Valve (EBCV) Mixture Control Valve (MCV) Electric Air Control Valve (EACV)
MDP	Manifold Differential Pressure	_
MFI	Multiport Fuel Injection	Electronic Fuel Injection (EFI)
MIL	Malfunction Indicator Lamp	Check Engine Lamp
MST	Manifold Surface Temperature	_
MVZ	Manifold Vacuum Zone	_
NVRAM	Non–Volatile Random Access Memory	_
O2S	Oxygen Sensor	Oxygen Sensor, O ₂ Sensor (O ₂ S)
OBD	On–Board Diagnostic	On–Board Diagnostic System (OBD)
OC	Oxidation Catalytic Converter	Oxidation Catalyst Convert (OC), CCo
OP	Open Loop	Open Loop
PAIR	Pulsed Secondary Air Injection	Air Suction (AS)
PCM	Powertrain Control Module	_
PNP	Park/Neutral Position	_
PROM	Programmable Read Only Memory	_
PSP	Power Steering Pressure	_
РТОХ	Periodic Trap Oxidizer	Diesel Particulate Filter (DPF) Diesel Particulate Trap (DPT)
RAM	Random Access Memory	Random Access Memory (RAM)
RM	Relay Module	_
ROM	Read Only Memory	Read Only Memory (ROM)
RPM	Engine Speed	Engine Speed
SC	Supercharger	Supercharger
SCB	Supercharger Bypass	E-ABV
SFI	Sequential Multiport Fuel Injection	Electronic Fuel Injection (EFI), Sequential Injection
SPL	Smoke Puff Limiter	_
SRI	Service Reminder Indicator	-
SRT	System Readiness Test	_
ST	Scan Tool	-
ТВ	Throttle Body	Throttle Body
тві	Throttle Body Fuel Injection	Single Point Injection Central Fuel Injection (Ci)
тс	Turbocharger	Turbocharger
тсс	Torque Converter Clutch	Torque Converter

тсм	Transmission Control Module	Transmission FCI1 FCT FCI1
тр		
TR	Transmission Range	-
TVV	Thermal Vacuum Valve	Bimetallic Vacuum Switching Valve (BVSV)
		Thermostatic Vacuum Switching Valve (TVSV)
TWC	Three–Way Catalytic Converter	Three–Way Catalytic (TWC)
		Manifold Converter
		CC _{RO}
TWC+OC	Three–Way + Oxidation Catalytic Converter	CC _R + CCo
VAF	Volume Air Flow	Air Flow Meter
VR	Voltage Regulator	Voltage Regulator
VSS	Vehicle Speed Sensor	Vehicle Speed Sensor
WOT	Wide Open Throttle	Full Throttle
WU-OC	Warm Up Oxidation Catalytic Converter	_
WU-TWC	Warm Up Three–Way Catalytic Converter	_
3GR	Third Gear	_
4GR	Fourth Gear	_